

Manual, Assembly instruction: Brodit 853846

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the instrument panel frame and the padded part of the dashboard, to widen the gap.

2. Press the curved edge on the left side of the ProClip into the gap above the gap opener. Pull out the gap opener.

3. Flip the ProClip towards the air vent so the curved edge on the left side of the ProClip hooks behind the instrument panel frame. Press the gap opener into the gap between the padded part of the dashboard and the climate control. Press firmly forward on the ProClip so the grooved edge goes into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.