

Manual, Assembly instruction: Brodit 853847

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the right side of the ProClip into the gap in the sidewall.
2. Flip the ProClip towards the stereo so the curved edge on the right side of the ProClip hooks behind the sidewall. Place your index finger behind the ProClip and pull it towards you. Hook it over the console edge so the grooved edge rests towards the wood grain panel.
3. Press firmly forward on the left side of the ProClip so the grooved edge goes into the gap between the wood grain panel and the console edge. Press until you see or hear/feel it snaps into place.
4. The ProClip is in place.