

Manual, Assembly instruction: Brodit 853850

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded part of the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener.
3. Press firmly forward on the lower left side of the ProClip so the grooved edge goes into the gap between the center console panel frame and the padded part of the dashboard. Press/wiggle on the top and bottom of the mount until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.