


Manual, Assembly instruction: Brodit 853851

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts: Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the console edge, to widen the gap. Place it in the same position as in the picture, in the same height. Peel off the cover of the adhesive tape on Part 1. Place the angled edge of Part 1 against the gap above the opener.

2. Press the angled edge firmly into the gap and at the same time bend Part 1 to the right until you hear/feel it snaps into place and the adhesive tape attaches to the console edge. Pull out the gap opener.

3. Press a screwdriver (Philips) through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Do not attach the tape yet. Screw Part 2 onto Part 1 using the enclosed screws. Press the ProClip to the right for optimal adjustment of the mount. Hold it in that position and tighten the screws.

4. The ProClip is in place.