

Manual, Assembly instruction: Brodit 853852

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the upper part of the ProClip over the edge of the dashboard ledge.

2. Press down on top of the ProClip with you one hand and pull and steer the lower part of the ProClip with you other hand so the angled edge hooks under the air vent edge.

3. The ProClip is in place.

4. The ProClip is in place.