

Manual, Assembly instruction: Brodit 853853

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the wood grain panel and the dashboard ledge panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Place the curved edge on the upper part of the ProClip into the gap next to the gap opener.
3. Press down on top of the ProClip so the angled edge hooks under the air vent edge. Pull out the gap opener.
4. The ProClip is in place.