

Manual, Assembly instruction: Brodit 853856

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts. Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Peel off the cover of the adhesive tape on Part 1. Press the angled edge firmly into the gap between the center console panel frame and the console edge.

2. Bend Part 1 to the right until you see or hear/feel it snaps into place and the adhesive tape attaches to the console edge.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Do not attach the tape to the center console panel frame yet. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip to the right with your thumb and index finger for optimal adjustment of the mount. Hold it in that position and tighten the screws.

4. The ProClip is in place.