

Manual, Assembly instruction: Brodit 853857

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the speaker grill and the dashboard, to widen the gap. Press the curved edge on the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Flip the ProClip down towards the air vent. Place your index fingers behind the ProClip and pull the angled edge over the dashboard edge and hook it into the gap between the dashboard edge and the air vent panel frame.

3. The ProClip is in place.

4. The ProClip is in place.