

Manual, Assembly instruction: Brodit 853859

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the ProClip into the gap between the speaker grill and the dashboard.

2. Flip the ProClip down towards the air vent. Place your index fingers behind the ProClip and pull the angled edge over the dashboard edge and hook it into the upper part of the air vent panel.

3. The ProClip is in place.

4. The ProClip is in place.