

Manual, Assembly instruction: Brodit 853866

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in exactly the same position as shown in the pictures.

1. Peel off the adhesive tape covers on the ProClip. Place the right end of the ProClip directly above the gap in the frame surrounding the control panel. Press the curved edge on the right part of the ProClip into the gap in the center console sidewall.

2. Pull the ProClip towards you and leftwards so the curved right edge hooks into the gap.

3. Hook/Press the angled edge on the left part of the ProClip into the gap between the control panel and the surrounding frame.

4. The ProClip is in place.