Manual, Assembly instruction: Brodit 853868

Angled mount, High NOT for wood grain panel.

1.)

2.)

3.)

4.)

Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers. Press until you hear/feel it snaps into place. Pull out the gap openers.

3. Press the gap openers into the gap between the frame surrounding the air vent and the dashboard. Press forwards on the upper part of the ProClip so the grooved edge goes into the gap between the gap openers. Press until you hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.