

Manual, Assembly instruction: Brodit 853870

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the left part of the ProClip into the gap above the gap opener. Flip the ProClip rightwards so the curved left edge hooks under the control panel. Pull out the gap opener.
3. Press forwards on the right side of the ProClip so the angled edge on the right part hooks behind the frame surrounding the control panel.
4. The ProClip is in place.