

Manual, Assembly instruction: Brodit 853880

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the frame surrounding the control panel, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers. Press until you hear/feel it snaps into place. Pull out the gap openers.

2. Press a gap opener into the gap between the frame surrounding the air vent and the dashboard to the left of the ProClip. Hook/press the left corner of the angled upper edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard to the right of the ProClip. Press the right corner of the angled upper edge of the ProClip into the gap so the angled upper edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.