

Manual, Assembly instruction: Brodit 853883

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame. Peel off the adhesive tape cover on the ProClip.
2. Place the upper edge of the ProClip, with adhesive tape, in the upper part of the air vent so the adhesive tape attaches.
3. Press the lower part of the ProClip upwards and then forwards so the lower edge hooks into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.