

Manual, Assembly instruction: Brodit 853884

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Open the glove compartment. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the long right part of the ProClip behind the edge of the dashboard by the glove compartment.
3. Pull the ProClip towards you and hook the left part, with adhesive tape, into the gap above the gap opener. Pull out the gap opener. Close the glove compartment.
4. The ProClip is in place.