

Manual, Assembly instruction: Brodit 853900

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape cover on Part 1. Press the angled edge on Part 1 into the gap above the gap opener.

2. Press Part 1 rightward so the angled edge hooks behind the control panel and the adhesive tape attaches to the dashboard. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape is to the left. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.