

Manual, Assembly instruction: Brodit 853901

Center mount NOT for models with factory navigation.



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip upward/forward so the curved lower edge hooks behind the control panel

3. Hook the angled edge on the upper part of the ProClip over the edge of the dashboard. Press downward on top of the ProClip so the angled edge hooks properly into place and the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.