

Manual, Assembly instruction: Brodit 853902

Angled mount Will block cup holder.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Hook the angled edge on the left part of the ProClip over the frame surrounding the control panel.
3. The ProClip is in place.
4. This ProClip can be installed in desired position, the picture shows a higher installation.