

Manual, Assembly instruction: Brodit 853904

Center mount Will block cup holder and table.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.
3. Flip/press the ProClip upward/forward so the curved lower part hooks behind the air vent and the angled edge on the upper part of the ProClip hooks over the dashboard. Press downward on top of the ProClip so the angled edge hooks into place properly and the adhesive tape attaches. Pull out the gap opener.
4. The ProClip is in place.