

Manual, Assembly instruction: Brodit 853905

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip into the lower part of the air vent.
2. Press forward on the lower part of the ProClip so the angled lower edge hooks into the gap between the climate control panel and the surrounding frame.
3. The ProClip is in place.
4. The ProClip is in place.