

Manual, Assembly instruction: Brodit 853909

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place/press the angled edge on the left side of the ProClip onto the silver gray trim.

2. Press firmly forward on the right side of the ProClip so the angled edge goes into the gap between the information window and the surrounding panel frame. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.