

Manual, Assembly instruction: Brodit 853910

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console sidewall and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the right side of the ProClip into the gap above the gap opener.
3. Place your fingers on the right side of the ProClip and press the ProClip towards the stereo so the angled edge on the left side of the ProClip snaps/hooks over the console edge. Pull out the gap opener.
4. The ProClip is in place.