

Manual, Assembly instruction: Brodit 853923

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the climate console panel frame and the dashboard overhang, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip upwards, towards the air vent. The curved edge on the lower part of the ProClip will then hook behind the climate control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the panel surrounding the air vent and the dashboard. Press firmly forward on the left side of the ProClip so the grooved edge goes into the gap below the gap opener. Press until you see the thin grooved edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.