

Manual, Assembly instruction: Brodit 853939

Angled mount Placed below air vent.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the air vent sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the right side of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the center console panel and the air vent panel, to widen the gap. Press the ProClip firmly to the left so the left angled edge on the ProClip goes into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.