

Manual, Assembly instruction: Brodit 853940

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the left side of the ProClip into the gap between the instrument window and the surrounding panel frame, towards the upper corner.

2. While keeping the curved edge in the gap, slide the ProClip down towards the instrument panel frame ledge.

3. Press the thin end of the enclosed gap opener into the gap between the dashboard and the center console trim, to widen the gap. Push the ProClip to the right so the angled edge on the right side of the ProClip goes into the gap above the gap opener. Press firmly forward on the ProClip faceplate until you see or hear/feel it clip into place. Pull out the gap opener.

4. The ProClip is in place.