

Manual, Assembly instruction: Brodit 853941

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the glove compartment frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hold the ProClip in a horizontal position and press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Flip the ProClip down, towards the floor, and hook the angled edge on the lower part of the ProClip into the gap underneath the dashboard overhang. Press until you see or hear/feel it snaps into place.
4. The ProClip is in place.