

Manual, Assembly instruction: Brodit 853945

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the ProClip on top of the gap opener. Slide the ProClip into the gap to the left of the gap opener.

2. Continue to slide the ProClip over to the left. Make sure the angled edge stays in the gap.

3. Place your fingers behind the front part of the ProClip. Pull the ProClip towards you and hook the angled edge around the dashboard edge. Pull out the gap opener.

4. The ProClip is in place.