

Manual, Assembly instruction: Brodit 853947

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding panel frame.
2. Press down on the top part of the ProClip and hook the grooved edge into the air vent edge.
3. The ProClip is in place.
4. The ProClip is in place.