

Manual, Assembly instruction: Brodit 853951

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

3. Press forward on the upper part of the ProClip so the grooved edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.