

Manual, Assembly instruction: Brodit 853954

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed.

2. Press the angled edge on the left part of the ProClip into the gap between the gap openers. Pull out the gap openers.

3. Press the gap openers into the center console side wall. Press forward on the right side of the ProClip so the angled edge snaps into the gap between the gap openers. Pull out the gap openers. Press on the ProClip so the adhesive tapes attach properly.

4. The ProClip is in place.