

Manual, Assembly instruction: Brodit 853955

Center mount NOT for models with factory navigation or large display.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the display and the surrounding panel
2. Slide the ProClip leftward, as far as possible, toward the steeringwheel.
3. Press downward and forward on the ProClip so the angled edge on the lower part goes into the gap between the panel surrounding the display and the panel surrounding the air vent.
4. The ProClip is in place.