

Manual, Assembly instruction: Brodit 853959

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the grooved edge on the left part of the ProClip into the gap between the gap openers.

2. Pull out the gap openers. Slide the ProClip downward, as far as possible.

3. Press the gap openers into the gap between the frame surrounding the control panel and the dashboard. Use one of the gap openers to prize the gap a bit wider. Press the angled edge on the right part of the ProClip into the gap between the gap openers. Pull out the gap openers.

4. The ProClip is in place.