

Manual, Assembly instruction: Brodit 853960

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap on top of the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward so the curved edge hooks into the gap.

3. Pull the ProClip towards you, press it downward and then hook the angled edge on the lower part over the dashboard overhang. Pull out the gap opener.

4. The ProClip is in place.