

Manual, Assembly instruction: Brodit 853965

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the left part of the ProClip into the gap between the panel over the instrument panel and the dashboard.

2. Flip the right part of the ProClip downward so the curved left edge hooks into the gap and the grooved edge on the right part of the ProClip goes into the gap between the gap openers.

3. Press downward on the right part of the ProClip so the grooved edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.