

Manual, Assembly instruction: Brodit 853966

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part Part 2. ProClip face plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on Part 1. Press the angled edge on Part 1 into the gap between the control panel and the surrounding frame.

2. Press Part 1 rightward so the angled edge hooks behind the control panel and the adhesive tape on the right end attaches to the control panel frame.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes fit and the adhesive tape is to the left. Screw part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.