

Manual, Assembly instruction: Brodit 853967

Angled mount, High NOT for models with factory navigation or large display.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hold the ProClip in an almost 45 degree angle towards the display/information window and press the curved edge into the gap between the display/information window and the dashboard panel ledge

2. Push the ProClip down towards the ledge so the curved edge hooks underneath the display. Slide the ProClip rightward, as far as possible in the gap.

3. Place both your hands behind the ProClip face plate and pull the ProClip towards you. It may seem too short but the ProClip will now flex towards you. Hook the angled edge into the gap between the dashboard and the panel ledge. Press forward on the lower part so the angled edge goes all the way into the gap.

4. The ProClip is in place.