

Manual, Assembly instruction: Brodit 853969

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the control panel and the panel surrounding the air vent, to widen the gap. Peel off the adhesive tape cover on Part 1. Press the angled edge on Part 1 into the gap between the gap openers. Press Part 1 rightward/forward and slide it downward in the gap until it stops.

2. Press forward/rightward on Part 1 so the angled edge hooks behind the frame surrounding the control panel and the adhesive tape attaches. Pull out the gap openers.

3. Open up the predrilled hole in Part 2 with a screw driver (Philips). Peel off the adhesive tape covers on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.