

Manual, Assembly instruction: Brodit 853970

Center mount NOT for Day Cab.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap a bit below the air vent. Peel off the adhesive tape covers on the ProClip. Press the left part of the ProClip into the gap in the dashboard.
2. Press/slide the ProClip downward so the lower corner of the right part goes into the gap above the gap opener.
3. Press/slide the ProClip downward so it is properly in place. Pull out the gap opener. Press forward on the ProClip so the adhesive tapes attach to the dashboard.
4. The ProClip is in place.