

Manual, Assembly instruction: Brodit 853972

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is very important to place the ProClip in the exact same position as shown in the pictures.

- 1.** Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the coin compartment, to widen the gap. Peel off the adhesive tape covers on the ProClip.
- 2.** Press the angled edge on the upper part of the ProClip into the gap between the gap openers.
- 3.** Pull the ProClip downward and press the lower part forward so the angled edge hooks into the gap between the frame surrounding the stereo and the frame surrounding the air vent. Pull out the gap openers.
- 4.** The ProClip is in place.