

Manual, Assembly instruction: Brodit 853973

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Remove the screw in the upper left corner. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the curved edge on the left part of the ProClip into the gap below the gap opener. Flip the ProClip forward/rightward so the curved left edge hooks behind the frame surrounding the control panel
3. Adjust the right part of the ProClip so the hole matches the hole in the dashboard. Screw the ProClip into place with the enclosed screw. Pull out the gap opener. Close the glove compartment.
4. The ProClip is in place.