

Manual, Assembly instruction: Brodit 853979

Angled mount NOT for models with upper glove compartment.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the panel surrounding the air vent and the dashboard.

2. Flip the ProClip downward and press it forward so the upper curved edge hooks behind the panel surrounding the air vent. Hook the angled edge on the lower part of the ProClip under the edge of the dashboard.

3. Press upward on the lower part of the ProClip so the angled edge hooks properly under the edge and the adhesive tapes attach to the dashboard.

4. The ProClip is in place.