

Manual, Assembly instruction: Brodit 853981

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward so the upper curved edge hooks under the frame surrounding the air vent. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the display and the dashboard. Pull the ProClip toward you/downward and hook the angled edge on the lower part into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.