

Manual, Assembly instruction: Brodit 853982

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard.

2. Flip the ProClip/pull it toward the steering wheel. Hook the angled edge on the left part of the ProClip into the gap below the gap opener.

3. Press forward on the left edge of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.