

Manual, Assembly instruction: Brodit 853984

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the angled edge on the upper part of the ProClip onto the dashboard next to the center console. Press down on top of the ProClip, in the same time pull it toward you so the angled upper edge hooks into the gap between the dashboard and the center console.

2. Pull the lower part of the ProClip toward you.

3. Press the lower part of the ProClip downward and hook the angled edge under the upper edge of the air vent.

4. The ProClip is in place.