Manual, Assembly instruction: Brodit 853985

Angled mount NOT for models with factory navigation.

1.)

2.)

3.)

4.)

Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the control panel and the surrounding frame, to widen the gap. Open the glove compartment. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard.

2. Press + slide the ProClip downward in the gap until it reaches a stop.

3. Press the angled edge on the left part of the ProClip into the gap below the Gap Opener (Spaltöffner). Press on the ProClip so the adhesive tape attaches and the angled edges go all the way into the gap. Pull out the Gap Opener (Spaltöffner). Close the glove compartment.

4. The ProClip is in place.