

## Manual, Assembly instruction: Brodit 853988

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Loosen the screw in the control panel a bit. Use the eclosed gap opener to slightly prize loose the control panel. Press the thin end of the gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

**2.** Press the angled edge on the right part of the ProClip into the gap below the gap opener. Pull out the gap opener. Press the gap opener into the gap between the control panel and the dashboard. Press the angled edge on the left part of the ProClip into the gap above the gap opener.

**3.** Press on the ProClip until you hear/feel it snaps into place properly. Pull out the gap opener. Retighten the screw.

**4.** The ProClip is in place.