

Manual, Assembly instruction: Brodit 853989

Center mount NOT for models with navigation screen.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the stereo and the dashboard, to widen the gap.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.