

Manual, Assembly instruction: Brodit 853990

Center mount, Low. NOT for models with navigation screen.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gaps between the frame surrounding the stereo and the dashboard (in the same positions shown in the picture), to widen the gap.
2. Place the ProClip by the gaps between the frame surrounding the stereo and the dashboard. Press the grooved edge on the lower part of the ProClip into the gap above the gap opener.
3. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Press forward on both ends until you hear/feel they snap into place. Pull out the gap openers.
4. The ProClip is in place.