

## Manual, Assembly instruction: Brodit 853991

Angled mount NOT for models with navigation screen.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts.** Part 1. Attaching part (the smallest part) Part 2. ProClip face plate.

**1.** Press the thin end of the enclosed gap opener into the gap between the frame surrounding the stereo and the dashboard, to widen the gap.

**2.** Peel off the adhesive tape cover on Part 1. Press the angled edge on Part 1 into the gap above the gap opener. Press Part 1 forward/rightward so the angled edge goes all the way into the gap and the adhesive tape attaches to the dashboard. Pull out the gap opener.

**3.** Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the adhesive tape is to the left and the holes match. Attach Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

**4.** The ProClip is in place.