

Manual, Assembly instruction: Brodit 854000

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Hook the angled edge on the lower part of the ProClip under the upper edge of the air vent.

3. Press forward on the ProClip so the angled edge on the upper part of the ProClip goes into the gap next to the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.